



June 2023

**xsens**

Release notes  
MVN 2023.2

# MVN 2023.2 release notes

<b>New versions</b>	<b>MVN: 2023.2 Stable (June 2023)</b> Awinda firmware: <b>(unchanged)</b> AW-A2 v4.6.0, AW-DNG2(-ANT) v4.6.0, MTw2 v4.6.0 Link firmware: <b>(unchanged)</b> BPACKv1 v1.6.1, BPACKv2 v1.6.1, MTx2 v1.6.1 FWU: 4.3.1 <b>(unchanged)</b>
<b>Previous versions</b>	MVN: 2023.0 (Jan 2023) Awinda firmware: AW-A2 v4.6.0, AW-DNG2(-ANT) v4.6.0, MTw2 v4.6.0 Link firmware: BPACKv1 v1.6.1, BPACKv2 v1.6.1, MTx2 v1.6.1 FWU: 4.3.1
<b>Release date</b>	June 2023
<b>Operating system</b>	Windows 10, 64-bit
<b>Meaning of icons</b>	+added, ^changed, !note, #fixed, -removed

## 1 Introduction

This document describes the new features, improvements, and bug fixes in the new release 2023.2 for Xsens software: MVN Record, MVN Analyze Plus, MVN Analyze Pro, MVN Animate Plus and MVN Animate Pro.

## 2 Major improvements and new features

### 2.1 MVN

- + Support for Delsys Duo & Quattro sensors
- + Update Delsys SDK to 2.5.2.

## 3 Bug fixes

### 3.1 MVN

- # The field "Side length" in Preferences was left-aligned. Now: right-aligned, like the other numerical fields.

## 4 Minor updates

-

## 5 Known Issues

- ! When using only 1 StretchSense glove, it will appear twice in Mocap Configuration dialog ("Left Stream ID" and "Right Stream ID" show the same glove).
- ! With streaming gloves (e.g. StretchSense) the "hardware-status-panel" does not show "Gloves not OK" warning when no data is received. If gloves are fully configured, but data is interrupted, this warning also doesn't show.

- ! When actor/subject walks out of range of the HTC/Steam VR base stations, the mocap quality has a high chance to provide low- and unreliable quality.
- ! Using OBR (On-Body Recording) i.c.w. GNSS (GPS) may result in pelvis- and torso 360- degrees rotation(s) (after HD reprocessing).
- ! When exporting an mvns file with multiple actors of different record time exports might be wrong